

410154- Trade Deck mixer

Useful Information				
Minimum operating pressure	0.1 bar			
Maximum operating pressure	5 bar			
Guarantee length	2 years			



Technical Diagram





ltem Number	Supplier Ref	Item Description	Quantity	Material	Spares Available
1	P01-A	Indice	2	ABS	Yes
2	SC4-10S	Screw	2	Stainless Steel	Yes
3	P01-C H	Indice Seat	1	ABS	Yes
4	P01-C C	Indice Seat	1	ABS	Yes
5	H01-C	Handle	2	ZINC	Yes
6	VS5412-BZ20	Valve	2	BRASS+EPDM	Yes
7	M0112-01	Tap Body	1	BRASS	No
8	OR016	Washer	2	EPDM	No
9	N15-G NP	1/2" Back Nut	2	BRASS	No
10	N12-B	O Ring	1	EVA	Yes
11	N08	Washer	2	NBR	Yes
12	N01-C	1/2" Back Nut	2	ZINC	Yes
13	SC4-7.5S	Screw	1	Stainless Steel	Yes
14	OR014	O ring	1	EPDM	Yes

15	OR015	O Ring	1	EPDM	Yes
16	M33247-N1	Block Ring	1	POM	Yes
17	M0112-02-01	Washer	1	POM	Yes
18	167020-02	Spout	1	BRASS	No
19	A1 3-04X	Washer	1	EPDM+Stainless Steel	Yes
20	A13-02	Flow straightener	1	POM	Yes
21	A14-04	Flow straightener Shell	1	ABS	Yes

Flow Rates

What should I do if my tap is dripping/leaking?

Cleaning the valve (if water dripping from tap)

Before carrying out any maintenance, turn off the mains water supply. If unsurecontact a qualified tradesman.

- 1. Remove the cap, grub screw and handles.
- 2. Remove the valve using a suitable spanner, clean thoroughly under cold water to remove any build up of limescale or debris.
- 3. If necessary replace the valve.
- in the sand ine 4. Replace the valve into the body, tighten the valve using a suitable spanner.
- 5. Replace the handles and indices, tighten the grub screw and re-fit cap to handles.

What does the Guarantee Cover?

The Guarantee Covering leakage, manufacturing defects and Chrome plating.

The guarantee does not cover:

Damage or defects caused by:

- general wear and tear (including special non-chrome finishes;
- components such as filters, seals, 'O'rings and washers)
- incorrect installation
- repair using non- PPI parts
- accidental or wilful misuse
- corrosion and the use of inappropriate cleaning products.
- system debris including the build up of limescale (which can be controlled through regular servicing and maintenance).
- Compensation for loss of use of the product or consequential loss of any kind.

FAQ

Mr. Oil Boor Con