





Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = AA, AD ..



Position

- 1 = A 960 645 XX
- 3 = B 960 473 XX
- 5 = A 960 646 XX
- 9 = A 962 716 NU
- 17 = A 960 647 NU
- 21 = A 960 650 NU
- 23 = A 960 651 XX




ATTITUDE
 A 4756 ..







0914 / A 866 058
 (+ A 865 612)
 Made in Germany



Ideal Standard International BVBA
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P	bar	MIN. 1.5		MAX. 5	Q (1.5 bar) l/min 3.5
	T	°C	MAX. 80		65 55	