







Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Зпасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļi

Pos.	Part No.
1	F 960 850 AA
2	A 860 603 NU
3	F 960 854 AA
5	A 960 230 NU
6	F 960 855 NU
7	F 960 856 NU
9	A 961 114 NU
10	A 962 294 NU
11	F 960 843 NU
15	B 960 432 NU
16	F 960 857 AA
17	A 962 370 NU
18	A 962 215 AA
19	A 961 172 NU
20	A 961 230 AA




	P	bar				
	T	°C				l/min
						5




sottini

MELITO
A 6486 .. A 6487 ..

0116 / A 868 079
 (+ A 866 385)
 Made in Germany



A 6486 ..







A 6487 ..



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com





	P bar	0,5		5		Q (3 bar)
	T °C		MAX. 80	65		l/min 5

