

VOLA 090, 090A, 090B:
VOLA 090C, 090D, 090E:
VOLA 090G, 090H, 090I, 090V:


1 - 4

VOLA 090FM:

5



Fitting instruction
Montageanleitung
Monteringsvejledning

Monteringsvægledning
Montage hanleiding
Manuel de montage




www.vola.com


mnt_090_V4_40999824
01-03-2023




Ø19: (VR38)
090A




Ø19-40: (VR38A)
090A




Ø19: (VR38L)
090
090B
090G
090H
090I
090V






Ø19-40: (VR38)
090
090B
090G
090H
090I
090V





Ø24: (VR638)
090C
090D
090E



Ø24-40: (VR633)
090C
090D
090E







VR17L9K: VR15P, VR16L9, VR17L
 VR437: VR98, 2xVR444, VR450, VR451



vola
 Lunavej 2
 DK-8700 Horsens
 Tlf : + 45 7023 5500
 sales@vola.com
 www.vola.com

VOLA 090V

Date
 Apr. 12

Rev.
 3

Sheet
 SB 19.5