



VOLA HV1E
VOLA RB1E

Fitting instruction
Montageanleitung
Monteringsvejledning
Monteringsvægledning
Montage hanleiding
Manuel de montage



HV1E/RB1E	L	H	h
Std.	114 mm 4 1/2"	150 mm 6"	56 mm 2 1/4"
/150	150 mm 6"	150 mm 6"	56 mm 2 1/4"
+170	114 mm 4 1/2"	320 mm 12 5/8"	227 mm 9"
+170/150	150 mm 6"	320 mm 12 5/8"	227 mm 9"




Data, 3 Bar:


Max.	l/min.	Gal/min.
HV1E:	5,0	1.3
RB1E	5,0	1.3

Max. 70°C, 158°F

1



2




3




4

HV1E



4A

RB1E



5

HV1E
RB1EHV1E2
RB1E2

