


VOLA HV1, HV3, HV4

Fitting instruction
Montageanleitung
Monteringsvejledning
Monteringsvægledning
Montage hanleiding
Manuel de montage



HV1, HV3:
04/00020
04/00028








www.vola.com



HV1/HV3/HV4_V6_40999827
01-01-2023



HV1, HV3	L	H	h
Std.:	114 mm 4 1/2"	120 mm 4 3/4"	27 mm 1"
+30:	114 mm 4 1/2"	150 mm 6"	56 mm 2 1/4"
/150:	150 mm 6"	120 mm 4 3/4"	27 mm 1"
+30/150:	150 mm 6"	150 mm 6"	56 mm 2 1/4"
+170:	114 mm 4 1/2"	290 mm 11 1/2"	197 mm 7 3/4"
+170/150:	150 mm 6"	290 mm 11 1/2"	197 mm 7 3/4"





3



4 mm

4




US 9/16"

ROW G3/8"

5

HV1L/HV1M
HV3L/HV3M
HV4L/HV4M




VR273L/M

2 mm



5



Data, 3 Bar/43.5 Psi:


Max.	l/min.	Gal/min.	Note.
HV1/3:	5.0	1.3	Standard
HV1/3:	4.5	1.2	Standard USA
HV1/3:	9.0	1.8	Standard Japan
HV4	9,0	1.8	




Max. 70°C, 158°F




HV1




HV3



HV4





 vola Lunavej 2 DK-8700 Horsens Tlf : + 45 7023 5500 sales@vola.com www.vola.com	HV4 Family: HV4, HV4L, HV4M	Date Jan. 23
		Rev. 7
		Sheet SB 24.1